




四隅を写す
テープ / Tape / 胶带

Keep
corners in video
テープ / Tape / 胶带

Focus

Focus

Focus

Focus

Focus

Focus

Focus

Focus

Focus

Start

Goal

テープ / Tape / 胶带

保持
初始中的四角
テープ / Tape / 胶带

Shoe-Craft-Terminal